


DISPLAY

A


Watch hands



CORRECTION MODE

B

Crown 3 positions



Normal running position
(correctors inactive)

Positions the hands to their origine
(Correctors activ)

Position for setting the time with
stop second and correction of the
date at every passing of midnight

Note

Setting crown in position III : **STOP-SECOND**

GB USA

ETA G15.562 BF PWD



ETA SA Manufacture Horlogère Suisse
depuis 1793


622 374 - 19.11.2015 / ETA / 01

POSITIONS THE HANDS TO THEIR ORIGINE

C

Setting crown in position II

Counter selection:
- date
- month
- day
(The selected hand
tours).




Resets the
selected counter
hand.
(The selected hand
moves).

CORRECTION MODE

D

Setting crown in position III


Counter selection:
- year
- month
- date
- day



The selected hand
moves.

Sets the
selected counter
hand

Counter selection:
- year / leap year



The year is displayed by the hand in
the centre, with the digits 1 - 4.
(The year of number 4 is the leap year)